

**231L frost free top mount in white finish. Featuring a humidity controlled full-width crisper, FlexStor door bin storage solutions and easy clean glass shelves.**

RRP AUS \$649.00



## Product Details

### FEATURES

---

Full-width humidity controlled  
crisper bin

FlexStor™ door bin storage  
system

Adjustable easy clean glass  
shelves

Door alarm

---

Chiller drawer

Multi-flow air delivery system

Frost free

R600a refrigerant  
better for the environment

---

Adjustable levelling feet  
(front)

---

### BENEFITS

---

#### Humidity controlled crisper

Offers the perfect environment for preserving fruit and vegetables, as well as having a removable crisper front for easy cleaning

#### Adjustable solutions with FlexStor™

As your family changes and grows, so do the requirements of your fridge. With FlexStor™ you enjoy the convenience of being able to easily change the configuration, whatever your needs. Adjust the height and position of the door bins to fit in large and smaller items and arrange your fridge your way.

---

#### Easy to clean with glass shelves

Glass shelves improve visibility and are easy to clean

---

## Specifications

### PRODUCT PROFILE

Domestic warranty details (yrs)	2
Additional domestic warranty for the sealed refrigeration system only (yrs)	3
Refrigerator Type	top mount
Exterior door finish	White
Fridge door opening	right
Cooling system	frost free
Refrigerant	R600a

### DIMENSIONS

Total height (mm)	1405
Cabinet height (mm)	1360
Total width (mm)	540
Cabinet width (mm)	540
Total depth (mm)	615
Cabinet depth (mm)	540
Depth door open 90degree (mm)	1108
Air space above cabinet (mm)	90
Food compartment capacity (gross in litres)	155
Freezer compartment capacity (gross in litres)	76
Total Gross Capacity (L)	231
Food compartment capacity (net in litres)	149
Total Net Capacity (L)	211

## ENERGY

---

Energy Star Rating	2
--------------------	---

---

Energy consumption (KWhr/yr)	407
---------------------------------	-----

---

## FOOD COMPARTMENT

---

### DELI-COMPARTMENT

---

Full width compartment	1
------------------------	---

---

## CRISPERS

---

Crisper lid/shelf	plastic
-------------------	---------

---

Crispers Runner system	floor
------------------------	-------

---

Full width crisper	1
--------------------	---

---

Crisper features	humidity controlled
------------------	---------------------

---

## FOOD COMPARTMENT DOOR

---

### BINS

---

## REFRIGERATOR SYSTEM

---

Controls	manual
----------	--------

---

Controls location	internal
-------------------	----------

---

Control functions	quick freeze function
-------------------	-----------------------

---

Door alarm	fridge
------------	--------

---

## SHELVING

---

Shelf material	glass
----------------	-------

---

## LIGHTING

---

Main light	LED
------------	-----

---

## FREEZER COMPARTMENT

---

### ICE FACILITY

---

Deep bottle bin 1

---

Ice cube tray 1

---

**SHELVING**

---

Shelving plastic shelf

---

Number of shelves 1

---

**FREEZER DOOR**

---

**INTERNAL**

---

Freezer door bins - full width 1

---

## Terms and Conditions

### IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

### PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

### WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

#### ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640

fax: 1800 350 067

email: [customercare@electrolux.com.au](mailto:customercare@electrolux.com.au)

web: [www.electrolux.com.au](http://www.electrolux.com.au)

#### ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230

fax: 09 573 2221

email: [customercare@electrolux.co.nz](mailto:customercare@electrolux.co.nz)

web: [www.electrolux.co.nz](http://www.electrolux.co.nz)