



HDW13V1W1

Dishwasher

With Delay Start function so you can get the dishes done at your convenience. Auto Wash setting optimises water and energy consumption for a more sustainable wash.

FINISH White

[Where to Buy](#)

[OVERVIEW](#) [FEATURES & BENEFITS](#) [SPECIFICATIONS](#) [RESOURCES](#)

Dishwasher

- AUTO wash to optimise your water & energy usage
- Height adjustable upper basket
- Lock function - to stop accidental opening
- Soft touch LED controls
- Water rating (WELS) - 4.5 star

Height
850mm

Width
598mm

Depth
598mm

Features & Benefits

Auto Wash

Automatically optimises wash cycles by sensing how dirty your dishes are

Adjustable Upper Basket

Create room to fit larger dishes up to 290mm tall in the lower basket

Safety Lock

Stops small hands accidentally opening the door

Soft Touch LED Controls

Easy to use and keep clean

Specifications

Capacity and Loading

Place settings 13

Performance

Noise emissions 51 dBA

Spray levels 2

Consumption

Energy Consumption (Normal Eco program) 285 kWh

Energy rating 3 stars

Water consumption per cycle 11.7L

Water rating (WELS) 4.5 stars

Product dimensions

Depth 598mm

Height 850mm

Width 598mm

Controls

Control type Soft touch LED

Wash Programs

Auto •

Eco •

Glass •

Heavy •

Light •

Number of wash programs 6

Rinse •

Features

Adjustable height, foldable cupracks •

Child lock •

Delay start 1-24hrs

Height adjustable top basket •

Memory •

Natural dry system •

Resources

General

[↓ User Guide](#)

Dishwasher, GeneralFiles-HaierAU