

300L chest freezer, white with lightweight, spring loaded lid RRP ${\rm AUS}~\$849.00$





Product Details

FEATURES

| Quick chill function | Removable, high insulation door seal | Hovering Door | Removable Baskets |
|----------------------|--|-------------------|--------------------|
| Power-off Protection | Ultra Thin Hinges | Recessed Handle | Mechanical Control |
| Adjustable Legs | R600a refrigerant better for the environment | White Inner Liner | |

BENEFITS

Chill out with Quick Freeze

Quick Freeze brings the temperature of your freezer down to freeze food quickly. Keeping food frozen after your grocery shop will mean fresher, tastier and more nutritious food that lasts longer.

Hovering door

The hovering door design allows you to open and leave the door at any angle between 30 and 60 degrees, allowing you to pack or unpack your freezer without the need to hold up the freezer door.

Removable baskets

Baskets can be removed to allow more storage space. When in use they keep the freezer neat and organised.

Power off protection

This new chest freezer is able to keep the inside temperature at 0 degrees for 135 hours after powering off.

Ultra-thin hinges

Short on space? The ultra-thin hinges on the chest freezer, allows you to place it right up against the wall.

Mechanical Control

Simply turning the temperature knob, you can set the temperature of the cabinet as you need, making sure that all kinds of food will be kept in the right condition.

Recessed Handle

This modern design of the luxurious recessed handle in round corner, perfectly fits into any existing kitchen design and easy to clean

R600a refrigerant

More environmentally friendly



Specifications

PRODUCT PROFILE

| Domestic warranty details (yrs) | 2 |
|---------------------------------|---------------|
| Refrigerator Type | chest freezer |
| Exterior door finish | White |
| Handle design | integrated |
| Cooling system | cyclic |
| Freezer door opening | top |
| Refrigerant | R600a |

DIMENSIONS

| Total height (mm) | 847 |
|---|------|
| Cabinet height (mm) | 766 |
| Total width (mm) | 1114 |
| Cabinet width (mm) | 1108 |
| Total depth (mm) | 630 |
| Cabinet depth (mm) | 610 |
| Height with lid open | 1405 |
| Air space above total height (mm) | 100 |
| Freezer Compartment Capacity AS/NZS IEC 62552-3 (L) | 300 |
| Total Capacity AS/NZS IEC 62552-3 (L) | 300 |

ENERGY

Energy Star Rating AS/NZS 3.5 IEC 62552-3

FREEZER COMPARTMENT

BASKET/DRAWER



Full width wire baskets

1




ENERGY

Energy Consumption AS/NZS IEC 62552-3 (kWh/year) 275



Dimensions



Minimum Recommended Airspaces

Before you move your appliance into the place where it will operate, check that it will have adequate clearance. Clearance is required for air circulation and too little clearance may affect the performance of your appliance.

| Dimensions | Product Height (H) | Product Width (W) | Product Depth (D) | Product Height (H2) (Door Open) |
|------------|--------------------|-------------------|-------------------|------------------------------------|
| WCM7000WE | 873 | 2145 | 758 | 1550 |
| WCM5000WE | 847 | 1646 | 717 | 1517 |
| WCM3000WE | 847 | 1114 | 630 | 1405 |
| WCM2000WE | 854 | 802 | 559 | 1342 |
| WCM1400WE | 854 | 625 | 559 | 1342 |

∫В

| Airspace | Side - both | Тор | Behind (B) |
|-----------|-------------|-----|------------|
| WCM7000WE | 100 | 100 | 100 |
| WCM5000WE | 100 | 100 | 100 |
| WCM3000WE | 100 | 100 | 75 |
| WCM2000WE | 100 | 100 | 75 |
| WCM1400WE | 100 | 100 | 75 |

IMPORTANT

These dimensions are a guide only. All measurements are in millimetres (mm). For complete installation instructions, refer to the manual provided with product.

© 2021 Electrolux Home Products Pty Ltd. ABN 51 004 762 341.

W_DIM_CF_WCM7-5-3-2-14000WE_Oct21



Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous productdevelopment, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products PtyLtd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640 fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230 fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz