

Kibo Button Set

KBO4470

Finishes available:



Chrome

Brushed
Nickel[^]
(.SN)


Matte
Black
(.MB)

Brushed
Gun Metal
(.GM)

Brushed
Brass[^]
(.BB)

Gloss
White
(.GW)

[^] PVD finish



CARE AND MAINTENANCE

- All surfaces should be frequent cleaned with a mixture of mild, pH neutral soap and warm water with a soft cloth
- Do not use abrasive clothes, scouring pads on surfaces
- Do not use harsh cleaning agents i.e. cream cleaners or citrus based cleaners (*see cleaning leaflet for comprehensive list*)

