

# Freestanding dishwasher with cutlery tray for maximum convenience at an attractive entry level price.

## G 4203 SC Active




- «
- Save up to 40% electricity - Thermo Save
- Easy loading and unloading - Cutlery tray
- Convenient operation - ComfortClose
- Every piece of crockery has its place – Miele basket design

<b>Type of appliance</b>	
Freestanding dishwasher	•
60 cm dishwasher	•
<b>Design</b>	
Colour	Stainless steel CleanSteel
Fascia panel version	Straight fascia
Control type	Programme selector
Display	3-digit 7-segment indicator
Display colour	Yellow
<b>Convenience</b>	
Door closing aid	ComfortClose
Countdown indicator	•
Delay start up to 24 hours	•
In-operation indication	Control display
<b>Efficiency and sustainability</b>	
Water consumption in the ECO programme in l	14,0
Water consumption in Automatic/Sensor wash programme in l	13,5
Consumption values with ThermoSave® in ECO programme in kWh	0,38
Hot water connection	•
<b>Gentle treatment of crockery and glassware</b>	
Recirculation turbothermic drying	•
<b>Dishwashing programmes</b>	
ECO	•
Automatic (Sensor wash)	•
Intensive 75°C	•
Normal 55°C	•
Gentle	•
<b>Dishwashing options</b>	
Short	•
<b>Basket design</b>	
Cutlery loading	Cutlery tray
Basket design	Comfort
<b>Technology and quality</b>	
Sensor technology	AutoSensor
<b>Safety</b>	
Waterproof system	•
Child safety lock	•
<b>Technical data</b>	
Niche width in mm	600
Niche height in mm	845
Niche depth in mm	600
Appliance width in mm	598
Appliance height in mm	845
Appliance depth in mm	600
Appliance depth with door open in mm	119,5
Net weight in kg	57,0
Total connected load in kW	2,2
Voltage in V	230
Fuse rating in A	10
Number of phases	1
Standard electrical frequency	50
Length of water inlet hose in m	1,50
Length of water drain hose in m	1,50
Length of electrical cable in m	1,90

Freestanding dishwasher with cutlery tray for maximum convenience at an attractive entry level price.

G 4203 SC Active



Stand-Geschirrspüler G6000