14cm built-in warming drawer with variable temperature control, versatile functionality and push to open with soft closing drawer. Designed to suit Electrolux 700 and 800 series 60cm built-in ovens

Product Details

FEATURES

Keep warm function

Plate warming function

Defrost setting

Easy to operate

Full drawer extension

BENEFITS

Keep plates ready for serving
The convenient Built-In Warming Drawer is your ideal companion in the kitchen keeping your plates and food warm and ready to be served.

Easy, Mechanical Control
Mechanical Control allows you to simply set the warming drawer, so your dishes and food are always as you like them.

THE OVEN'S PERFECT COMPLEMENT
Designed with the chef in mind, the Warming Drawer is the perfect complement to your oven's design keeping dishes and food warm and ready to serve.

KEEP FOOD AND DISHES WARM
Serve every dish at its best with the built-in Warming Drawer. Warm plates, prove dough or keep food heated until its time to serve perfect for preparing many courses for family and friends.

KEEP IMPORTANT ITEMS AT HAND
Perfectly aligned for your built-in kitchen, the Storage Drawer store plates, glasses, sous vide bags and more.

Specifications

PRODUCT PROFILE

Domestic warranty details (yrs)	3
Type	built-in

FEATURES

Number of place settings	6
Features	Cups & Glass warming (40d °C),Plate Warming (60d °C),Anti-slip mat,Overheat protection,Variable temperature control,Defrosting (30d °C),Dough proving (40d C-50d °C),Food warming (60d C-80d °C)

EXTERIOR

Exterior Finish	Black glass
Push to open drawer system	yes
Full drawer extension	Yes
Soft close door	Yes

SPECIFICATIONS

Power	Plug
Maximum Power Rating (W)	400

DIMENSIONS

PRODUCT

Total height (mm)	139

FLUSH

Cut out height (mm)	141

Total width (mm)	594
Total depth (mm)	530

Cut out width (mm)	560
Cut out depth (mm)	550

SHIPPING

Shipping Volume (m3)	0.08723
Shipping Weight (Kg)	14.8
Pack dimensions height	220
Pack dimension width	610
Pack dimension depth	650

Dimensions

Model:
LBD4Z



Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous productdevelopment, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes theproducts that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products PtyLtd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours ofproducts illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA
telephone: 1300 363 640
fax: 1800 350 067
email: customercare@electrolux.com.au
web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND
telephone: 09 573 2230
fax: 09 573 2221
email: customercare@electrolux.co.nz
web: www.electrolux.co.nz